



# TROY SOCC BATTLE RAIL INSTALLATION



## **WARNING:** BEFORE USING A FIREARM, READ AND FOLLOW INSTRUCTIONS

IF THERE IS ANYTHING YOU DO NOT UNDERSTAND, GET HELP FROM SOMEONE QUALIFIED IN THE SAFE HANDLING OF FIREARMS. OBSERVE SAFE FIREARM HANDLING PRACTICES AND WEAR SAFETY GLASSES AT ALL TIMES. MAKE SURE THE FIREARM IS UNLOADED AND SAFETY IS ENGAGED BEFORE STARTING DISASSEMBLY.



1. Delta ring and front sight assembly have to be removed and a low profile gas block needs to be installed.



2. Install the clamps (tapered end towards the barrel nut) and screws provided and tighten until they're snug.



3. Loosen the four screws by two full turns with 5/32 allen wrench. (provided)



4. Slide rail onto barrel nut while rotating rail 5 degrees "clockwise" until flush with receiver, then rotate back to align rail with upper receiver.



5. Holding rail into position, tighten the four retaining clamp screws evenly. (For best results use thread locking compound.)

**IMPORTANT NOTE:** Due to the low profile nature of the TROY SOCC BattleRails™, the rail may not fit over your muzzle device with the clamps installed. You may need install the clamps after the installation holes clear the muzzle device.

**WORLDofTROY.com**

Clarksville, TN U.S.A.

(866)788-6412 | [tech@troyind.com](mailto:tech@troyind.com)

Copyright © TROY 2025 | SOCC Rail Instructions